



hello@moduquip.com



www.moduquip.com



## **CABINPUMP Installation Checklist**

**IMPORTANT** – This checklist must be read in conjunction with the CABINPUMP operating manual. Ensure CABINPUMP chamber lid remains closed at all times.

Action		Check
1.	Place CABINPUMP unit in required location and ensure it is flat and level	
2.	Connect 4" waste from building into the pre-formed inlet position(s). Ensure unused inlets are capped off	
3.	Connect 63mm* pumping main to the CABINPUMP using the supplied compression fitting and provide frost protection if necessary.  *Preferred specification 63mm SDR17 PE100 Black	
4.	Connect the 16A plug into a suitable power supply	
5.	Ensure the pumping main is adequately supported/braced so there is no strain on the outlet section of the CABINPUMP	
6.	Double check inlet and outlet connections	
7.	Fill CABINPUMP 1/2 full with clean water through the connected inlet(s)	
8.	If safe to do so, open control box cover and turn the power isolator to the 'ON' position	
9.	Wait for 60 seconds for the system to program	
10.	Press and hold 'Pump 1' button until the 'HAND' light illuminates – continue to hold for 10 seconds after the pump has started then release	
11.	Press and hold 'Pump 2' button until the 'HAND' light illuminates – continue to hold for 10 seconds after the pump has started then release	
12.	Press 'Pump 1' button until the 'AUTO' light illuminates	
13.	Press 'Pump 2' button until the 'AUTO' light illuminates	
14.	Allow the CABINPUMP to fill again to test the automatic pumping cycle	
15.	The system is now in automatic mode. Close and lock the control panel	

If you have any questions or queries, please contact us to speak to an engineer.



+44 (0)330 390 4114



hello@moduquip.com



www.moduquip.com



## **CABINPUMP Disconnection Checklist**

**IMPORTANT** – This checklist must be read in conjunction with the CABINPUMP operating manual. Ensure CABINPUMP chamber lid remains closed at all times.

Actio	Action	
1.	Ensure CABINPUMP is still connected to the power, incoming waste connection and pumping main.	
2.	Turn on a continuous water supply to the unit for approximately 10 mins to allow the CABINPUMP and pumping main to flush itself through with clean water.	
3.	Turn off the water supply and open the clear-fronted enclosure to access the control panel.	
4.	Press and hold down the 'P1' and 'P2' buttons together and run the pumps together manually until you hear the 'snore', or the water level is too low for the pumps to drain any further.	
5.	Using the isolator on the control panel, turn the CABINPUMP off and lock the control panel enclosure.	
6.	Unplug the CABINPUMP from the power supply.	
7.	Disconnect any waste inlet(s) and the pumping main from the unit.	
8.	Move the system into an accessible location ready for collection.	

If you have any questions or queries, please contact us to speak to an engineer.